

## Westfalia Roof Canvas Fitting Instructions

1. You will need about 5 to 8 hours and 1 to 2 people to help to fit a roof canvas.
2. To take a few pictures on the details of the fitting on the old canvas could be helpful later.
3. Check all dimensions on the canvas and on the roof to make sure it is a right roof canvas.
4. Remove the screws on side aluminium moulding first, and then on the front and rear mouldings.
5. Remove the old canvas and clean your roof a bit.
6. Use a screw driver to remove the tack strips with which the old canvas were attached to the pop-top.
7. Buy some new tack strips or use the old ones if they are OK.
8. Remove 3 bolts in the front of the pop-top on the reinforced bar to remove the bar.
9. Remove the bolts on each side of the lifting gear , one on the flank and one on top in order to get ready to remove the whole pop-top unit.
10. Tie off the lifting gear and use poles or stick to support pop-top.
11. Remove the pop-top from the hinges which are hold by 3 nuts each.
12. Take the whole pop top off the roof and put it upside down to a plain surface.
13. Mark the middle point of each edge of canvas and the pop-top.
14. Use staple gun to install canvas to pop top from the middle points to corners, a staple every 5 inches maybe.
15. Put the tack strip over the stapled area and tackle the strip one staple every 2 inches.
16. Clamp the material by cloth clamps to stop the material in the way when turning the pop-top over.
17. Put the pop-top back on to roof and bolt it to the hinges.
18. Drill through the canvas and tack strips to reinstall the lifting gear to the pop-top. Fasten the 4 bolts on both sides.
19. Install the reinforcement bar by fasten the 3 bolts in the front of the pop-top.
20. To install the canvas to the body, you need to clamp the canvas between the aluminium mouldings and the roof . Start from short moulding at the front and then to the side ones. Make sure the middle points are all in line with and you start from the middle to corners.
21. Finish installing the corners, notch the plastic welting in corners to make the turn and remove mattress if necessary.
22. Here we go! Job Done!