

Fitting Instructions for Cool Out Hammock for VW T2 Bay

Part number: C9040

Included in the box:

1x hammock canvas

4x brackets

4x spacer washers

4x 2cm length screws

4x 1.5 cm length screws

2 x male hammock bars

2x female hammock bars

How to fit the hammock


Please note that the Cool Out hammock bars will fit the original VW Westfalia bay window support brackets without any modification. If fitting to a westfalia the holes may have been predrilled ready for the installation of a hammock.

The hammock bars are telescopic and therefore can be placed at any height desired. Please note the canvas when installed should be drum tight and sufficient room should be left below the bars, so that when a child is placed in the bed there is sufficient room to clear the steering wheel and the top of the dashboard. Placing the hammock too high may restrict the area in which a child may sleep.

Step1:

Mark and drill the holes for the brackets on the A pillar (windscreen side surround). The lower hole should be no less than 11cm from the top of the dashboard. The bracket must be installed at angle.

See photo (Front Bracket at Right Hand side A pillar)




Repeat the procedure on the other A pillar checking the measurement from the top of the dashboard.

Step 2: Attach the brackets to the A pillar. On the lower drilled hole place the spacer between the A pillar and the bracket attach the bracket using the longer 2cm length screw provided. The 1.5 cm screw is for the top hole in the bracket. Repeat the procedure on the other A pillar.

Step3: Measure and drill the holes for the B pillar bracket. If seat bulk heads are in place an accurate measurement can be made from the top of the bulk heads, the bottom hole should be drilled no less than 13 cm from the bulk head top.

The brackets must be installed at angle.

See photo (Rear Bracket at Right Hand side B pillar)



Step 4: Attach the bracket and spacer using the 2 cm screw to hold the spacer in place. Repeat the bracket installation on the other B pillar. Check all screws are tight.

First time Hammock assembly

Step1: Unfold your new canvas and place on a flat surface.

Step 2: Slide the male hammock support bar inside the female hammock support bar. Repeat this process with the other two bars.

Step 3: Slide each hammock support bar through the canvas. Make sure the hooked ends face inwards to the middle of the canvas.

Step4: Roll up the canvas with the hammock bars threaded through the canvas.

Attaching the hammock to the brackets.

Remove the headrests (if fitted).

Attach the hammock support bar to the brackets on the A pillar (wind screen surround). Unroll the canvas and attach the hammock support bar to the B pillar.

Handy tips

If there is built in furniture present near the bracket attach that side first.

Pull the seat belts slightly forward as they may obstruct .

Check the security of the hammock to brackets before placing an object on the canvas!